



KBWS Kissing Ball Workstation Instructions for Assembly and Use

GENERAL INFORMATION

The purpose of this manual is to assist the operator in operating, and maintaining the KELCO Kissing Ball Workstation. Read it carefully. It furnishes information and instructions that will help you achieve years of dependable performance.

The information in this manual was current at time of printing. Due to possible engineering changes your machine may vary slightly in detail. KELCO Industries reserves the right to design and change the machine as may be necessary without notification.

PACKING LIST

- 1 ea. Fully Assembled Kissing Ball Workstation
- 1 ea. 15 inch Steel Tube (Ball Pin) with one sample (KKB02H) Hanger inside.
- 1 ea. Set of instructions

OPERATING INSTRUCTIONS

1. Center kissing ball form over Ball Pin Tube and push down until base of ball rests on top of Pin Receiver.
2. Apply greens to top of ball, which will be bottom when kissing ball is finished.
3. Pull ball with greens attached off Pin Receiver. Flip ball over and push down until base rests on Pin Receiver once again with Ball Pin Tube still in place.
4. Apply additional greens until ball is completely covered.
5. Attach any decorations you may wish to use.
6. Insert kissing ball hanger down through center of Ball Pin Tube. Pull Ball Pin Tube out of bottom of ball, leaving hanger through center of kissing ball. Bend end of hanger, so it does not slip back through the ball.

MAINTENANCE

Your Kissing Ball Workstation requires no maintenance.

WARRANTY

Your Kelco product is sent to you directly from our factory. If you should have any problems that can not be resolved with your machine by the enclosed literature, call us at 1-800-343-4057. If it cannot be corrected, we will send you a new machine.

KELCO INDUSTRIES
PO Box 160 / Milbridge, ME 04658
Voice 800-343-4057 / Fax 207-546-2791
www.kelcomaine.com

Note: These instructions are for KELCO item KBWS as redesigned in 2014.