



SHRP1100 Rotary Pruner or SHRP1500 Basal Pruner Instructions for Assembly and Use

PACKING LIST

Pruner comes in **three** separate cartons.

CARTON ONE: Pruner Wand and Instructions

CARTON TWO: Echo 2000 Motor with Throttle Assembly , Instructions and T25 Torx Key

CARTON THREE: Pruner Head

ASSEMBLY INSTRUCTIONS

Open all cartons to insure packages are complete and parts are not damaged.

We recommend that you start with a six foot long work table.

1. For tools you will need the T25 Torx key which was provided with the motor , you will also need a small screw driver, a 3/8" wrench and a 5/16" wrench.
2. Start by loosening one or two turns, on all five of the fasteners on the side of the hand throttle section and also the two fasteners on the motor.
3. Position the motor with the air cleaner on top, then position the wand with the hump verticle. And the tool drive facing down.
4. Gently slide the wand ,without the cutting head installed, through the throttle assembly until it almost touches the grease fitting.
5. If the flex cable is engaged it will stick out only one inch. If it sticks out further you will have to twist it until you feel it go into place.
6. Using the T25 Torx key, tighten all seven of the fasteners until they are quite snug. If you can twist the motor or throttle section you will have to tighten it more.
7. With everything in place the flex cable should stick out one inch from the end of the wand.
8. Install the pruner head and go to work.

Head should be positioned so that CAUTION label is facing motor.

KELCO INDUSTRIES
PO Box 160 / Milbridge, ME 04658
Voice 800-343-4057 / Fax 207-546-2791
www.kelcomaine.com